
INSTALLATION

- > The Emergency Assist Alarm should be installed in accordance with the recommendations of BS8300 and to the requirements of Building Regulations Approved Document M.
- > The diagram below demonstrates a typical layout for installation in a disabled person toilet.

Note: Where pertinent other or alternative standards of design and installation should be adhered to.



- > All system components are designed to be sited internally and positioned in locations where they are readily accessible by the user. The area should be clean and dry and sound and light levels allow the status of all device indicators and sounders to be seen and heard.
- > Any likelihood of tampering or vandalism should also be taken into account at time of design.

OPERATION

To Place a Call Operate the Pull Cord. LED's will illuminate on, Pull Cord Unit, Cancel Unit and Over Door

Indicator. An internal buzzer will also sound in the Over Door Indicator.

VoCALL Unit

To Reset Call Press the Cancel Button.

MAINTENANCE

Weekly Clean plates with a non abrasive cleaning cloth and detergent, do not use harsh or solvent

based cleaners.

Monthly Test Call system by making and resetting a call.

BC5083-120 User Manual dolphinsolutions.co.uk