

Cleaning and maintenance instructions



Warranty only valid if installation instructions are followed.

Maintenance and Cleaning



- Use a cotton cloth for cleaning. Do not use rough cloths that can leave marks in the long term.
- Only use cleaners suitable for the respective surfaces.
- Cleaning should be carried out as necessary and in accordance with the instructions for use of the cleaner used.
- Never spray cleaner directly onto fittings and accessories, but apply it to a cleaning cloth and use it to clean.
- Do not use chlorinated or highly aggressive cleaners, alcohol, bleach, or thinners. These can cause surface corrosion and stain formation.
- In general, applied cleaners must be rinsed off with plenty of clean water.
- Even body cleansers such as soap, shampoo, and shower gel can cause damage. These substances should also be rinsed off carefully.
- Attention: avoid contact between our stainless steel products and ferrous materials (e.g., sponges, steel wool, and ferruginous water). Contact would lead to the formation of rust stains on the surface. Aerators must be cleaned regularly (also by disassembling them and removing deposits by tapping and rinsing). Use mild and natural cleaners, such as citric acid.



DISENIA

Disenia srl
via A. Carpenè, 21
33070
Brugnera (PN)
Italy

CUSTOMER SERVICE ITALY
Tel. + 39 0434 1822603
Fax. + 39 0434 020013
e-mail: info@disenia.it
www.disenia.it