

BAGNODESIGN NARA

CLEANING & MAINTENANCE



SANIPEXGROUP

WWW.SANIPEXGROUP.COM

NARA

BDF-NAR-L440-XX

NARA FREESTANDING BASIN LEG

Finish : MATT BLACK / NATURAL OAK



Instructions for maintenance and cleaning of solid ash wood lacquered with open pore

Solid ash wood feet lacquered with an open pore are precious items that require specific care to maintain their beauty and longevity over time. Please carefully follow the following instructions to ensure proper maintenance and cleaning.

Materials Needed:

Soft microfiber cloth
Warm water
Mild detergent for cleaning

Regular Cleaning:

Remove dust or superficial dirt using a soft dry microfiber cloth.
For persistent dirt or light stains, lightly dampen the cloth in warm water and wring it well. Gently wipe the affected surfaces.
Avoid using aggressive detergents, solvents, or abrasive products that could damage the lacquer or wood.

Deep Cleaning:

If necessary, prepare a solution of warm water and mild detergent in a small quantity.
Dip the soft cloth into the solution and wring it thoroughly to avoid excess moisture.
Gently clean the surface of the solid wood, taking care not to leave damp residues on the surface. Immediately dry with a soft, dry cloth.

Warnings:

Avoid the use of aggressive or abrasive chemical products that could damage the surface.

Instructions for maintenance and cleaning of solid oak wood

The collection comprises solid oak wood and, like all wooden items, demands specific care:
Wood surfaces require gentle handling as they are “living” materials sensitive to heat and moisture. Natural changes in color over time due to light exposure are not defects but natural features. The presence of knots, small holes, and surface imperfections signifies authenticity and adds value to the finish. These irregularities should be considered enhancements rather than defects. Variations in color or grain are natural characteristics of the product. This revised format aligns with the original structure provided for easier comprehension and reference.

Materials Needed:

-Damp cloth
-Common glass cleaning products (water and glass cleaner) or water and Marseille soap

Regular Cleaning:

ALWAYS WIPE the surface of the washbasin top after use to prevent limescale formation. Avoid placing soaps, cosmetics, or detergents that might stain the wooden surfaces.

Deep Cleaning:

For cleaning wooden surfaces:
Use a damp cloth with common glass cleaning products (water and glass cleaner) or water and Marseille soap. Dry any water droplets on wooden tops to prevent paint detachment due to increased wood moisture.

Warnings:

The furniture is coated with high-quality acrylic products. However, using aggressive detergents to remove stains from improper usage can damage the surface. Avoid abrasive products, acetone, chlorine, or thinners. Refrain from applying waxes or furniture polishes, as these can be damaging to the varnish.