



Installation Guide




AQA-ECO-703-XX
AQUAECO TOUCHLESS SOAP/SANITIZER DISPENSER 700ML

A member of SANIPEXGROUP www.sanipexgroup.com

Introduction



Dimension



Important Safety Instruction


To make sure the unit dose work and extend its lifespan under the good condition, please notice that:

- 1. Please read user manual and instructions very carefully before installing the unit.
- 2. Please using the same AA battery (6 pcs) of well known brand. Old and new batteries cannot be mixed. If counterfeit or low—grade batteries are used, it may do harm to the unit lifetime.
- 3. Please check the wall is flat or not and clean the surface of wall before installing the unit.
- 4. Distance (more than 25cm) will be needed from the bottom of unit to tables or other objects.
- 5. The instructions of installing will be given to the user or manager by qualified person.
- 6. Reflective objects must not be put in the sensing distance under the unit.
- 7. Please do not cover with reflective objects (such as mirror or stainless steel) on the table against the bottom of the unit, to avoid wrongly placed.
- 8. Indoor use only, to avoid wrongly placed.

Packing list

- 1. Unit x 1
- 2. Installation Panel x 1
- 3. ST4X25 Screw x 3
- 4. Installation Manual x 1
- 5. Expansion Screw x 3
- 6. Certification x 1
- 7. key x 1
- Please make sure if any items are missing or problems before installing, contact your dealer or manufacturer.
- 2. Specification of part items changed might be not informed in time, please contact your dealer or manufacturer when problems cannot be solved during installing.
- Main objects are sealed by special bag. Do not hit or drag too heavy when you move or open the bags.


Installation



Tips: Ensure the distance between sensing window and counter top is above 35cm When installing on stainless steel counter top.

Floor


Installation




1. Refer to step:5, remove mounting plate from the machine. Attach the mounting plate to the wall and draw the positions of three mounting holes with pencil.




2. Use a drill to bore three holes (\$6) according to the marks, put expansion screw head into the corresponding holes.



3. Screws will be matched with plastic nail heads in the wall, lix them together with mounting plate.




4. Align the upper slot of the machine with the mounting plate clip, then make the machine fit with the mounting plate, and then slide the machine downward to make the upper and lower clips all snap in.



5. Screw in the anti-theft screw, then install the battery box and screw in the anti-removal screw.

Battery Installing and Replacement



2. Keep the body straight up when 2. Unscrew the screw and remove 3. Put in or replace all standard the LED light is flashing.

the battery box.


batteries {(DC 9V/AA batteries (6 Pcs)}. Put it back and tighten the screws.



CAUTION

- 1. The unit includes electronic devices and solenoid valve, please do not knock.
- 2. Caution for connecting line when disassembling the unit.
- 3. Please wipe it using soft cloth with neutral detergent when cleaning the product. Next wipe detergent and dirt by the wrung—out soft cloth, then using dried soft cloth to drv.
- 4. Please do not washing with watering or using some detergent with particle such as scouring powder and laundry detergent, also do not using diluent, detergent with high acid or Nylon brush to clean this product, lest to damage surface or erode internal electronic components, especially be careful not to damage transparent cover which placed induction window to avoid decrease the effectiveness of reaction. Tips: Ensure the distance between sensing window and counter top is above 35cm When installing on stainless steel counter top. Installation.

How To Use



Insert the key into the lock to open the top cover after install the battery Long press the setting button for about 3 seconds, then the LED light on with flashing 3 times.

Open the sealing cap and pour the Put your hand under the sensor liquid soap, remove the extra over until the liquid sprayed out. wing, and recover it.






Children should be used under adult supervision to prevent accidentally eating! Please don't throw away discarded batteries, recycling used batteries by correct way! The unit has been designed with microcomputers & electronic circuit etc. Do not splash water.

- 1. After installing the batteries, long press the setting button for about 3 seconds, then the LED light on with a flashing, after 3 times flashing will the unit stay in standby, long press the setting button to switch between turning the machine standby Status and dormant status.
- 2. The unit is suggested to install batteries even if you don't use it, so that the unit will run automatically every 72 hours to avoid the catheter pressure adhesion.
- 3. Some of unit had installed batteries and in dormant status before delivery. Keep press setting buttons for more than 3 seconds, the indicator will flash 3 times turning into standby status. Whereas if the unit turn to dormant status after keeping press the setting button.

Liquid Adjustment

At the standby status, you can adjust liquid by pressing the liquid adjustment button. The default liquid volume output is around 1.0ml before delivery, it will increase around 0.5ml output for per press. Totally 5 levels adjustment with the range of liquid soap supply 0.5–2. Smt. Different liquid may have a slight deviation.



Liquid Adjustment Button

Troubleshooting

Problem	Reason	Potential Solution	
LED indicator off	Control system trouble	Replace the controller	
	Power supply problem	Check the Circuits and batteries	
	Batteries poor contract or out of power	Re—install or replace e the batteries	
	Circuit problem or poor contact	Check the Circuits	
	Block sight of indicator	Clean the indicator window	
LED light flash	Not enough power	Replace the batteries	
Indicator on	Sensor continue working	Remove the sensing object	
without liquid	Out of sensing distance	Contact the the dealer	
supply	Unit fault	Contact the the dealer	
Insufficient liquid	Short liquid supply time	Adjust the liquid output	
supply	Too viscous liquid	Reduce liquid viscosity	
	Liquid Coagulation or obstruction	Try sometimes or contact the dealer	
Tips: Please prevent debris from entering the container to avoid blocking.			

Specification

Material	304 stainless steel	Power	DC9V(6AA Batteries
Volume	700ml	Sensing Distance	5-9cm
Dimension	100 x 110 x 220mm	Liquid Supply	0.5ml-2.5ml (5 step adjustment)
Net Weight	1.1kg	Ambient temperature	0-45 °C

Note:	

