


ECOSCENT ARIEL



- Built in LCD timer system
- Wall mounted
- Battery or USB power supply



COLOUR OPTIONS




Grey



White

SPECIFICATION SHEET

Product Code: 001-102



PRODUCT SPECIFICATIONS


Product Name	EcoScent ARIEL
Dimensions	W112mm x D71mm x H182mm
Weight	450g
Coverage	100m ³
HVAC	No
Scent Chamber	100ml
Colour	Grey or White
Lifetime	10,000 Hours @ 45°
Operating Temp	0-50°C
IP Rating	IP54
Mounting	Wall Mounted
Minimum Noise	<50 Dba
Connection	DC 5V
Control	24hr / 7 Day Digital Timer / Scent Intensity Control
Power Consumption	2.5W
Supply Voltage	5V DC
Supply Current	0.41A
Scent Consumption	0.3ml / Per hour on 100% Concentration. Lasts approx. 62 days (based on 100ml used at 40% concentration, 10 hours a day)
Length of Product Tested	50pc
Input Voltage (V DC)	12 V
Input Power (W DC)	2.5W
Total Scent Output (m ³)	100m ³
Efficiency (SCENT /W)	40



ECOSCENT

Premium Scenting Solutions

PRODUCT MANUAL ARIEL



Please read the user manual carefully before using the product and keep it in a safe place.

Safety Precautions

1. Do not use overloaded power supplies, USB ports, sockets, or use damaged power cords and plugs. If used, it may endanger your safety and may cause fire.
2. Please do not open the inside of the scent delivery system as this may cause damage. If the scent delivery system works in error, please read the user manual carefully, follow the normal procedure or consult after-sales.
3. When the scent delivery system is working, do not disassemble the scent delivery system or shake the scent delivery system vigorously.
4. Do not put the scent delivery system or power adapter in water. Do not put water in the fragrance bottle.
5. When the scent delivery system is already filled with fragrance oil or cleaning solution, do not invert, tilt or rotate the scent delivery system to prevent liquid spillage and damage of the scent delivery system and surfaces.

In The Box

						
USB Cable	Hanging Plate	Key	See QR Code On The Box	Fixings	Hexagon Lock	3 x AA Battery





Product Instruction

The EcoScent ARIEL features advanced diffusion technology that converts fragrance oil into a fine, dry, mist, releasing fragrance safely and directly into your environment without sprays or aerosols. A sleek, elegant design, easy to install and reliable performance.

ARIEL uses a professional diaphragm pump which can work for 10,000 hours. The EcoScent Ariel has a built in LCD timer system to control the working time and aroma concentration based on your preference. Leading technology with patented micron atomisation makes the ARIEL'S aroma diffuse and spread quickly providing a long lasting fragrance.

MODEL NO.	ARIEL	DIMENSIONS	112 x 71 x 182 mm
OIL CAPACITY	100ML	N.W	450g
COVERAGE AREA	100 CUBIC METERS	VOLTAGE	DC5V
POWER	2.5W	NOISE	<45dba
OIL CONSUMPTION	0.3ML PER 100 ON 100%	INSTALLATION METHOD	Wall Mounted




Installation Instruction



Insert the key to unlock the cover, then take out oil bottle.

Put 3 AA battery into scent system (or connect USB power). Fill bottle with oil, and replace by clicking into scent system.

Set working/pause time and lock the cover to start.



Prepare your hanging plate.

Match the groove at the back of Scent Delivery System with the convex of hanging panel.

Tighten M3 screw into the position to fix machine, there is a locking screw to ensure the system remains secure to the wall.

Please ensure the unit is mounted with at least a 30cm distance between the unit and any surface above it such as a ceiling or table.

Settings



1. Turn power on, press the [MODE] up to 5 seconds to start the LCD Display.
2. The LCD displays the current hour minutes and work day. It also shows the current working state as: WORK ON, PAUSE ON, or PAUSE OFF.
3. Press [SET], then press [UP] or [DOWN] to adjust the hour, minute, or work day settings.
4. Press [MODE] to set Scent Delivery System's work period and WORK/PAUSE time. For example,
 - a. Press [MODE] once, this shows to adjust ON time of first work period. They press [SET] [UP] [DOWN], to adjust the the hour, minute and work days respectively.
 - b. Press [MODE] for second time, this shows option to adjust OFF time for the first work period. Then press [SET] [UP] [DOWN] to adjust the hour, minute and work day respectively.
 - c. Press [MODE] for third time, that shows the fixed setting -WORK for 3 seconds (not changeable).
 - d. Press [MODE] for fourth time, to set the PAUSE time within 100 - 900 seconds by pressing [UP] /[DOWN]

5. Please repeat the above steps to set 2nd / 3rd / 4th work periods.
6. Reset the default setting by pressing [MODE] for 10 seconds.
Default Setting: The ON time of 1st work period is 8:00, OFF time is 22:00.WORK time is 3 seconds, PAUSE time is 300 seconds. The 2nd/ 3rd /4th work periods stay in blank.
7. Switch to energy saving mode automatically if there is no operation for 10 seconds. Press any key to activate.
8. The red LED will flash when battery runs low.

Fragrance Concentration

The Scent system works for 3 seconds at a time and can be paused from 100-900 seconds per your requirements. The longer the pause, the weaker the fragrance.

CONCENTRATION %	WORK	PAUSE
100%	3s	100s
90%	3s	150s
80%	3s	200s
70%	3s	300s
60%	3s	400s
50%	3s	500s
40%	3s	600s
30%	3s	700s
20%	3s	800s
10%	3s	900s

Scent Delivery System Maintenance

For the scent delivery system maintenance advice please refer to "Clean-Me Guide" included with your purchase. Please ensure the fragrance oil is topped up regularly. Clean with cleaning solution every 2 months or if changing the fragrance.

Do not use the water in the scent system. Do not tilt the scent system.

Before using the scent system please ensure it is correctly installed and to be checked at least monthly. Damage may be caused by improper installation or if using non approved EcoScent fragrances. Please take care when handling fragrance oils and the scent system as any spillages may cause damage to fabric, flooring, surfaces, polished and painted areas. Any spillages of fragrance oils from the fragrance bottle or from the scent system should be cleaned up immediately.

Troubleshooting

FAULT	SOLUTION
SCENT DELIVERY SYSTEM IS NOT WORKING	<ul style="list-style-type: none">- Check the power supply.- Check if the power is on.- Check scent delivery system working time.
WEAK OR NO ATOMISATION	<ul style="list-style-type: none">- Check if the nozzle is blocked- Check if the oil pump tube is attached correctly.
OIL LEAK	<ul style="list-style-type: none">- Check if the scent system is upright.- Check the connection of the oil bottle and atomiser is closed tightly.
ABNORMAL NOISE	Please send video of the fault to ecoscent@ecoscent.co.uk

CLEAN ME GUIDE

It is important to regularly clean your scent delivery system with our EcoScent cleaning solution every couple of months to ensure the system runs smoothly and to prevent unnecessary internal damage.

STEP ONE



To clean the scent delivery system, ensure that fragrance oil bottle is empty then half fill with cleaning solution. Turn on the scent system to run as normal for 5-10 minutes.

STEP TWO



Turn off the power, pour out any residual cleaning solution and retain for future use.

STEP THREE



If the scent system is in constant use, the cleaning operation above should be carried out every 2-3 months to ensure ultimate efficiency of the atomised scent delivery technology.

If the equipment is not being used for a long period of time it is recommended that the fragrance oil bottle is emptied and the fragrance oil stored in a dry, dark, secure location. The scent system should then be cleaned with the cleaning solution as mentioned above. Please refer to User Manual for further information.

* Failure to clean the machinery will affect the warranty*