

 Device in which the protection against electric shock is not based solely on the isolation of the front, but also on additional safety measures consisting of double insulation or reinforced insulation. These measures do not require grounding devices and do not depend on installation conditions.

 It certifies the conformity of the product to the provisions of the community directives.

 The product at the end of its life must be disposed of in a separate collection center for electrical and electronic equipment.

- WARNINGS:-**
1. Read the INSTRUCTIONS carefully before starting the assembly.
 2. Appliance designed exclusively for interiors. $T_a = 25^\circ\text{C} \pm 15^\circ\text{C}$
 3. Keep these instructions for maintenance.

ASSEMBLY INSTRUCTIONS FOR THE LUMINAIRE

- 1a- Switch of the electrical system, the power supply voltage before assembly and any other maintenance intervention of the lighting equipment;
- 2a- Unscrew the two screws from the base of the lamp and fix the bracket to the wall with appropriate screws and fixing plugs;
- 3a- Connect the cables of the internal wiring of the appliance to the general power cables (230 V) via a junction box LTD mod.603, IP44 paying attention to match the conductors (brown color line and neutral blue color)
- 4a- Insert the lamp base on the wall bracket and tighten the two screws.
- 5a- Turn on the power supply at the general electrical board.

INSTRUCTION FOR MAINTENANCE: LAMP CHANGE

- 1b- Turn off the general switch of the electrical system, the power supply voltage before any electrical maintenance is undertaken;
- 2b- Unscrew the diffuser vertically and remove it from its seat;
- 3b- Make sure that the lamp has cooled down;
- 4b- With your hands, hold the lamp and take it out of the lamp holder;
- 5b- In the same way, reinsert the new lamp.
- 6b- Reinsert the diffuser.
- 7b- Turn on the power supply at the general electrical board.