





CARE INSTRUCTIONS

PFLEGEANLEITUNG INSTRUCTIONS D'ENTRETIEN ISTRUZIONI DI MANUTENZIONE



ΕN

Care instructions

You have selected a product with a high-grade surface. Please follow the care instructions below.

The manufacturer does not assume any liability for product damage that arises as a result of incorrect care and handling.

Care instructions for sanitary ceramic appliances

- Only use standard cleaning agents in accordance with the relevant manufacturer's instructions.
- Ensure that the WC seat, the bidet seat or the urinal lid is opened or dismounted during the application time of cleaning agents.
- Only use chlorine-based, abrasive or scouring cleaning agents in the event of heavy deposits.
- Never use cleaning agents that contain acid or that are corrosive.
- · Never use sharp or pointed objects when cleaning.

Dirt	Care measures
Daily cleaning	 Use mild liquid cleaning agents and water. Dry the surface with a soft, lint-free cloth.
Stubborn stains	 Use cleaning agents that are generally suitable for sanitary ceramics or a mild scouring liquid. Remove existing limescale deposits using a mild cleaner containing vinegar. Clean the surface with water. Dry the surface with a soft, lint-free cloth.
Heavy deposits	 Organic deposits (brown to black in colour): Clean the affected areas with a standard chlorine cleaner. Note the information provided by the cleaning agent manufacturer. The application time of the chlorine cleaner must not, however, exceed 2 hours. Clean the surface with water. Dry the surface with a soft, lint-free cloth. Silicate deposits (grey in colour): Wet a microfibre cloth with a standard ceramic glass cleaner. Clean the affected areas using circular motions. As silicate deposits are extremely resistant, several cleaning cycles may be required. Clean the surface with water. Dry the surface with a soft, lint-free cloth.