

BYSTRO

PRODUCT CARE AND MAINTENANCE

Product care

Periodic care with stainless steel surfaces is essential to prevent corrosion due to foreign matter that may settle on them.

For the care and cleaning we recommend using a neutral cleaning product and rinsing well with water. When done, dry with a soft cloth to avoid deposit of limescale residues.

Avoid the use of the following cleaning products:

- sanitizing products such as bleach, ethylene oxide, chloride, and non-ionic surfactants;
- products containing chloric, hydrofluoric, phosphoric, and muriatic acid;
- scouring pads, metal brushes or powder abrasive detergents.

Brushed and polished finishes

SURFACE OXYDATION : To remove surface oxidation from our products we suggest applying a small quantity of an oxalic acid-based cream using a soft cloth. Wipe with a clean cloth to get a bright surface.

SCRATCHES : For brushed finish, scratches or superficial alterations can be removed using an abrasive scotch-brite scouring pad by wiping it gently on the product surface in the same direction as the brushing..

PVD finishes

For a good maintenance of PVD treatment we suggest cleaning the product using a neutral cleaning detergent and rinsing well with water. When done, dry with a soft cloth to avoid deposit of limescale residues.