


BAGNODESIGN

EXPERTLY CRAFTED BATHROOMS

General Installation Guide



M-LINE

illuminated LED mirror



NOTE: for illustrative purposes only a 500 mirror is shown, please follow the same procedure to install the other products.

A member of  SANIPEXGROUP

Please leave these instructions with the customer

IMPORTANT PLEASE READ

Remove all packaging and check the product for missing parts or damage before starting installation.

Any alterations made to this product and fittings may infringe water regulations and invalidate the guarantee.

The Installation must comply with all Local/National Water Supply Authority Regulations/Byelaws and Building and Plumbing Regulations.

We strongly recommend that your product be installed by a reputable qualified trade's person.

General Installation:

To the Installer, please read and follow this instruction carefully, as the guarantee is only valid if the product is installed as directed.

Don't rush, read the instructions first and run through them before you begin. Keep fittings together to avoid loss. Do not over tighten screws or bolts.

If the product is covered with polyethylene protective film, do not remove until installation is complete to grant maximum protection. However, remove film where any two surfaces will be in permanent contact.

Please leave this installation manual with the end user once the product has been installed.

Product Aftercare:

We recommend cleaning with a soft damp cloth and mild soap solution. Do not use cream cleaners or cleaners containing bleach.

Do not scrub or scour.

Do not use abrasive cleaning agents.


Do not use solvent based cleaners.

Electrical Connections

All electrical connections and alterations should be carried out by a qualified electrician and be in accordance with Part P regulations.

All **BAGNODESIGN** mirrors are IP rated to different standards and are suitable for installation in various zones. The diagram below illustrates this zonal concept and must be followed to ensure safe installation of electrical bathroom products.

The diagrams and information below are a guide to Bathroom Zones as referred to in IP ratings it is important to install an electrical product in the correct bathroom zone i.e. the zone referred to in the IP rating of the product. This is not an installation guide, and reference should be made to the latest edition of the IEE wirings Regulations or a qualified electrician.




Zone 0 is inside the bath or shower tray itself. Any appliance used in this zone must be rated at least IP67 which is total immersion proof.

Zone 1 is the area above the bath or shower tray to a height of 2.25m from the floor. In this zone a minimum rating of IP44 is required and products must also be protected by a 30mA residual current device (RCD) to protect the circuit. The electrical connection to the power supply for these products must be in Zones 2/3 of the bathroom in compliance with BS7671:2001 - IEE Wiring Regulations.


Zone 2 is an area stretching 0.6m outside the perimeter of the bath and to a height of 2.25m from the floor. In this zone an IP rating of at least IP44 is required. In addition, it is good practice to consider the area around a washbasin, within a 60cm radius of any tap to be considered as zone 2.

TOOLS REQUIRED (Not supplied)



Drill and drill bits

Required when securing the mirror to a wall. Use an appropriate size bit to match the wall fixing chosen (wall screws and fixings may not be supplied).




Measure the distance between the brackets on the rear-side of the mirror, Calculate this distance into the final position of where the mirror will be hung, and mark the 2 points on the wall.




Drill the two marks to the depth of plug that will be used.




Insert the plugs into the wall, if slightly tight, tap in with a hammer.




Screw the screws into the plugs, take a measurement from the back-edge of the mirror to the bracket, this will ensure that the screw is protruding from the wall at the correct measurement for the bracket to catch.




Remove the electrical cover from the back of the mirror.



Allow plenty of wire flex from the wall to a place where the mirror can comfortably sit, connect the live and neutral wires into the terminal. Re-place the electrical cover.




2 persons may be required to hang the mirror, place the mirror above the screw fixings, then slowly slide down, the mirror can be slightly pivoted to allow vision of the screw fixings catching the bracket.



Turn on the mains power and test, *Installation is now complete!!!*

BAGNODESIGN

EXPERTLY CRAFTED BATHROOMS



Oakwell Way, Birstall
Leeds, England WF9 17LU

A member of  SANIPEXGROUP